



PARTNERS
FOR ENDOSCOPY

500ml First Step *Add Water* Bedside Kit (EP6W)



Our First Step 500ml **Flexible Endoscope Bedside Pre-Clean Kit** is sent to you with concentrated Simple2 Enzymatic Detergent. You simply dilute the concentrate by adding tap water into the stand up pouch. This can even be done in advance as a unique zip lock retains the mix ready for use. There is an easy-to-read fill line on a clear strip on the back of the pouch. This kit is economical to use, cost-effective and convenient to store.



We can supply a stand if required.

It is also environmentally friendly as it has a lower carbon footprint than alternative bedside kits, as they have less packaging (as audited under our ISO14001 Environmental quality standard).

For more information please call **01782 594164**
or via email **sales@pfmedical.co.uk**

Hartley House, Galveston Grove, Fenton, Stoke-on-Trent ST4 3PE www.pfmedical.co.uk

All prices are valid for 30 days and exclude VAT and Carriage

Last Updated Jan 2017